

UPGRADE TO 3.92 version

Insert the self-starting installation CD into your CD-ROM drive and install **ALL** the feature buttons in the installation program. Be sure you installed the USB remote Software. (It has a two-stage installation). **DO NOT QUIT INSTALATION AT THE END OF THE FIRST STAGE.** Just let it continue to install the second part. Go to c:\djpowers\djupdate, and install DJP-DX-Setup.exe. This will install **DIRECT X9a** version of Microsoft. Please do not use any other version of directX.

REMOTE USB

- 1- Plug remote into USB Plug
- 2- Be sure that you have fresh batteries in the remote.
- 3- Open DJPower. Go to Options, Advance2, Change keyboard&....
- 4- Click on "REMOTE RF /CONTROLLER, and click on Auto Search
- 5- You may receive a note that it can't find the remote. This is OK for the USB version.
- 6- Push OK and it puts you in the main DJPower screen.
- 7- Try the remote volume, pitch, etc. It should react to your command.